
Ademco Vista 40 Programming Guide

*Ademco Vista
40*

Programming Guide

Downloaded from

cardprinter.sendafriend.co

by Davies & Yamilet

MASTERING YOUR SECURITY SYSTEM: THE COMPLETE ADEMCO VISTA 40 PROGRAMMING GUIDE

For homeowners and security professionals alike, the Ademco Vista 40 remains a trusted workhorse in the world of residential and light commercial security systems. Known for its reliability, scalability, and relatively straightforward interface, this control panel offers a robust feature set that can be tailored to a wide

variety of security needs. However, to unlock its full potential, you need to understand how to navigate its programming environment. This comprehensive

Ademco Vista 40 programming guide

is designed to walk you through the essential steps, key commands, and best practices for configuring your system. Whether you are a do-it-yourself homeowner or a technician looking for a refresher, this guide will provide the clarity and detail you need to program your Vista 40

with confidence.

Understanding the Ademco Vista 40 Control Panel

Before diving into the programming sequence, it is important to appreciate what the Vista 40 offers. This panel supports up to 48 zones, multiple partitions, and a variety of keypad styles, including the alphanumeric models that make programming significantly easier. The system operates

on a menu-driven structure for installer programming, which is accessed using a specific sequence of keystrokes. The programming mode allows you to configure zone types, entry and exit delays, communication settings for central station monitoring, and user codes. A solid grasp of this foundational knowledge will make the programming steps outlined in this guide far more intuitive.

Entering the Installer Program

ming

Mode

The first step in any **Ademco Vista 40 programming guide** is gaining access to the installer menu. This is the gateway to all system configuration options. To enter the programming mode, you will need the installer code, which is typically set to 4112 at the factory. Perform the following steps on an alphanumeric keypad:

1. Press and hold the [*] and [#] keys simultaneously for approximately two seconds.
2. The keypad will beep, and the display may

prompt you to enter the installer code.

3. Enter the default installer code: 4112. If this code has been changed by a previous installer, you will need that new code to proceed.
4. Once entered, the keypad will display "Installer Programming" or a similar menu prompt, confirming you are now in the programming environment.

If you are using a fixed-word keypad, the process is similar, but the feedback will be provided via LED indicators rather than text prompts. For the most efficient programming experience, an

alphanumeric keypad is highly recommended.

Navigating the Programming Menu Structure

The Vista 40 programming menu is organized into a series of numbered fields. Each field corresponds to a specific function or group of settings. You navigate by entering the field number you wish to edit. The system uses a straightforward command set:

- **To go to a**

specific field:

Enter the field number (e.g., 1*56) and press [*]. The system will acknowledge the field.

- **To change a setting within a field:** Enter the new data and press [*] to save.
- **To exit a field without saving:** Do not press [*] after entering data; instead, press [*] again to clear the entry.
- **To exit programming mode:** Press [*] until the keypad returns to the idle display, or enter field 99 and press [*]. This will save all changes and exit.

Understanding this navigation logic is

crucial. It is a loop-based system, meaning if you reach the end of the fields, it will wrap back to the beginning. Do not be alarmed if you see a field number you did not expect; simply navigate to the correct field using the steps above.

Setting the Date and Time

Accurate date and time settings are essential for proper event logging and scheduled arming features. This is often one of the first tasks performed after entering programming mode. While you can set the clock from the user menu, it is also configurable within

installer programming. To set the time and date from the user level (which is often the most straightforward method after initial programming):

1. Enter your master user code (default is 1234).
2. Press the [*] key.
3. Press [4] for System Test or a similar menu option, depending on your keypad version.
4. Select the option to set the time and date, following the prompts to enter the current hour, minute, month, day, and year.

Within the installer programming, the time and date are generally set in a system-specific

field. Refer to your field list for the exact field number, but a common approach is to use the user menu after programming is complete. Ensuring the clock is correct will help you accurately review alarm history and schedule automatic arming and disarming.

points of your system, such as door contacts, motion sensors, and glass break detectors. Programming zones correctly is perhaps the most critical part of any **Ademco Vista 40 programming guide**. Each zone must be assigned a zone type, a response time, and a descriptive text label.

Program ming Zones: The Heart of Your Security System

Zones are the individual detection

ZONE TYPES

The Vista 40 supports a wide range of zone types. Selecting the correct one determines how the system responds when the zone is faulted. Common zone types include:

- **Type 01 (Entry/Exit 1):**
Used for the main entry door. It provides a fixed entry delay and an

adjustable exit delay.

- **Type 02 (Entry/Exit 2):** Similar to Type 01 but with a shorter entry delay, often used for a secondary entry point like a garage door.
- **Type 03 (Perimeter):** Used for interior doors and windows. An instant alarm if faulted when the system is armed.
- **Type 04 (Interior, Follower):** Used for motion detectors in areas that may be traversed during entry delay. It waits for the entry delay to expire before reporting an alarm.
- **Type 05 (Trouble Day/Alarm Night):** Produces a trouble beep during the day if activated and an alarm at night.
- **Type 07 (24-Hour Silent):** Always active, with no audible alarm. Ideal for panic buttons.
- **Type 08 (24-Hour Audible):** Always active, with a loud siren. Ideal for fire or smoke detectors.
- **Type 09 (Supervisory):** Used for devices that need monitoring, such as a sprinkler flow switch.

ZONE PROGRAMMING

STEPS

To program a specific zone, you will need to enter the zone programming field. For example, to program zone 1, you would enter field 1*56 (this is an example field; always check your specific panel's field map). Within this field, you will enter data that defines the zone attributes:

1. **Zone Type:**
Enter the two-digit zone type code (e.g., 03 for Perimeter).
2. **Partition Assignment:**
Enter the partition number (1 for a single partition system).
3. **Zone Number:**
This is often preset, but you confirm the zone

being programmed.

4. **Input Type:**
Specify whether the zone is hardwired (EOLR), normally closed, or using a wireless transmitter.
5. **Loop Number:**
For wireless zones, specify the transmitter loop (1 for the main sensor, 2 for a secondary sensor on the same transmitter).

After entering all the data for a single zone, press [*] to save and advance to the next zone. Continue this process for every zone on your system. Labeling each zone with a descriptive text (field 1*80 for zone descriptors) will make user operation much

simpler. Use names like "Front Door" or "Living Room Motion" for clarity.

Setting Up Partitions

The Vista 40 supports up to four partitions, allowing you to divide the premises into independently controlled areas. This is ideal for multi-tenant buildings, or for separating a home into main living areas and a garage or workshop. Each partition can have its own arming schedule, user codes, and keypad.

To program partitions, you will need to assign zones to specific partitions as described in the previous section.

Additionally, you will configure partition-specific settings in their respective fields. Key partition settings include:

- **Partition Master Code:** A unique master code for each partition (field 1*01 for partition 1, etc.).
- **Partition Arming Schedule:** Set auto-arm and auto-disarm times for each partition (field 1*41 series).
- **Partition Keypad Assignment:** Assign each keypad to a specific partition (field 2*00 series).

When setting up multiple partitions,

careful planning is essential. Consider how common areas will be accessed and whether users should have access to multiple partitions. The system allows for global arming actions that can arm or disarm all partitions simultaneously, which is a convenient feature for closing a large facility at the end of the day.

Configuring Communication and

Central Station Reporting

One of the primary reasons for installing a security system is to ensure that alarms are reported to a monitoring station. The Vista 40 supports both Contact ID and 4+2 reporting formats, which are the industry standards. To program communication, you will enter the central station's phone numbers and account information.

Key communication fields include:

- **Field 2*01 and 2*02:** Primary and secondary central station phone numbers. Enter the phone

number exactly as needed for your premises (including an initial digit like 9 if required for an outside line).

- **Field 1*80 (or similar):**

Account number for each partition. This is a four-digit number that identifies your account to the central station.

- **Field 2*03:**

Reporting format (Contact ID is highly recommended for its speed and reliability).

- **Field 2*10 and 2*11:**

Programming for communication test times. These fields dictate how often the panel sends a test

signal to the central station (usually every 24 hours).

After programming the communication settings, it is imperative to perform a communication test. This can be done from the user menu by selecting "Test" and then "Communicator Test." Wait for the central station to confirm they received the test signal. Without a successful communication test, your system will not be monitored effectively.

Customizing Keypad

Functions and User Codes

The user experience of your security system hinges on how well the keypads and user codes are configured. This section of your **Ademco Vista 40 programming guide** will help you create a user-friendly environment for the occupants.

USER CODES

User codes allow individuals to arm and disarm the system. The Vista 40 supports up to 48 user codes. User number 1 is always the Master Code, which has the authority to add, delete, or change other user codes. To

program a new user code from an alpha keypad, use the following steps:

1. Enter the Master Code and press [*].
2. Press [5] for User Codes.
3. Enter the user number (02-48) and press [*].
4. Enter the new four-digit code and press [*].
5. If the system prompts you for user attributes, you can assign authority levels (e.g., Arm Only, Full Access) at this point.

From the installer programming mode, you can also set user codes en masse, but the user menu method is often more practical for day-to-day management.

KEYPAD PROGRAMMING

Keypads on the Vista 40 can be customized to control which features are available at each location. For example, a keypad near an entry door might be programmed to allow full security functions, while a keypad in a child's

bedroom might only allow arming. Keypad options are programmed in field 2*00 series. Common settings include:

- **Keypad Partition Assignment:**
Ensures the keypad controls the correct partition.