
Pioneer Deh 1300mp Installation Guide

*Pioneer Deh 1300mp
Installation Guide*

*Downloaded from
cardprinter.sendafriend.co
by Singleton & Kobe*

GETTING STARTED WITH YOUR PIONEER DEH 1300MP INSTALLATION

Installing a new car stereo can transform your daily commute into a more enjoyable experience. The Pioneer DEH 1300MP is a reliable and affordable single-DIN receiver that offers CD playback, MP3 compatibility, and AM/FM

radio. If you have recently purchased this unit or are planning to swap out your factory radio, you have made a solid choice. However, before you can enjoy your favourite playlists, you need to get the unit properly fitted into your vehicle. This Pioneer DEH 1300MP installation guide will walk you through every step, from gathering the necessary tools to testing your new stereo. Whether you are a seasoned DIYer or a first-time installer, following

these steps will help you achieve a clean, professional result without unnecessary frustration.

WHY CHOOSE THE PIONEER DEH 1300MP?

Before diving into the installation process, it helps to understand what makes this model a popular option. The Pioneer DEH 1300MP is designed for straightforward functionality, making it an excellent choice for drivers who want improved sound quality without a steep learning curve. It features a built-in MOSFET 50-watt amplifier, which provides clear audio output even at higher volumes. The front auxiliary input allows you to connect portable music players, and the CD player supports MP3 and WMA files burned onto discs. Its

simple interface and blue illumination make it easy to use while driving. More importantly for this guide, the wiring and mounting system are standardised, making the physical installation manageable for most vehicle types.

TOOLS, MATERIALS, AND SAFETY PREPARATION

A successful installation depends on being properly prepared. Trying to improvise halfway through often leads to damaged wires, scratched dashboard panels, or an improperly secured stereo. Before you begin, gather the following items so that you can work efficiently.

Essential Tools for the Job

- **Phillips-head and flat-head screwdrivers** – These are needed for removing dashboard screws and prying off trim panels.
- **Wire strippers and crimpers** – Used to strip insulation from wires and attach crimp connectors securely.
- **Electrical tape or heat shrink tubing** – Provides insulation for exposed wire connections to prevent short circuits.
- **Panel removal tool or trim pry tool** – Helps release factory clips without damaging the dashboard.

- **Socket wrench set** – Useful for removing bolts that secure the factory stereo bracket.
- **Multimeter or test light** – Allows you to confirm which wires carry constant 12V power, switched power, and ground.

Components You Will Need

- **Pioneer DEH 1300MP stereo unit** – Ensure you have the full package including the trim ring and mounting sleeve.
- **Dash kit or mounting bracket** – Required for most vehicles to adapt a single-DIN aftermarket

radio to the factory opening.

- **Wiring harness adapter** – Plugs directly into your vehicle's factory connector, saving you from cutting the original wires.
- **Antenna adapter** – Needed if your car uses a different antenna plug than the standard size found on the Pioneer unit.

Safety First

Disconnect the negative battery terminal before doing any electrical work. This eliminates the risk of short circuits and protects both you and the vehicle's electronics. Wait at least ten minutes after disconnecting the battery to allow any residual charge in the airbag system capacitors to dissipate. If your vehicle

has a security code for the factory radio, make sure you have the code or a backup plan before disconnecting power.

REMOVING THE FACTORY STEREO

With your tools assembled and the battery disconnected, you can begin removing the factory radio. The exact method varies between vehicles, but the basic steps are similar across most makes and models. Patience is important here because forcing trim pieces can result in broken clips or scratched surfaces.

Locate and

Remove Trim Panels

Most vehicles have a plastic trim bezel surrounding the radio and climate controls. Use a panel removal tool to gently pry the trim away from the dashboard. Start at a seam or edge, working your way around until the trim piece comes free. If you encounter resistance, check for hidden screws that might be holding the trim in place. Once the trim is removed, set it aside in a safe location where it will not get scratched.

Unscrew the Factory Radio

After the trim is out of the way, you will see several screws or bolts securing the factory radio bracket. Use the appropriate screwdriver or socket wrench to remove these fasteners. Carefully slide the factory stereo out of the dashboard opening. You may need to disconnect the wiring harness and antenna cable from the back of the unit. Take note of how the factory harness is connected, as this might help you later when connecting your new wiring.

Identify the Wiring

Once the factory radio is free, examine the wiring harness. If you are using a harness adapter, plug it into the vehicle side. This adapter will have bare wires on the other end that you will connect to the Pioneer harness. If you must cut the factory connector, leave enough wire length to allow for a clean splice. However, using an adapter is strongly recommended because it makes future removals easier and preserves the original wiring integrity.

WIRING THE PIONEER DEH

1300MP HARNESS

The wiring stage is the most critical part of the installation. A mistake here can lead to a dead stereo, blown fuses, or even damage to the unit. The Pioneer DEH 1300MP comes with a dedicated wiring harness that uses standard colour codes. Matching these colours to your vehicle wires or harness adapter ensures proper power, ground, and speaker connections.

Standard Pioneer Wire Colour

Codes

- **Yellow** – Constant 12V battery power. This wire maintains memory for presets and clock settings.
- **Red** – Switched 12V ignition power. The stereo turns on and off with the ignition key.
- **Black** – Ground connection. Must be connected to a clean metal chassis ground point.
- **Blue/White** – Power antenna or amplifier turn-on lead. Provides 12V output when the stereo is on.
- **Orange/White** – Illumination/dimmer wire. Connects to the vehicle's lighting circuit to dim the display with the

dashboard lights.

- **Gray** – Right front speaker positive (+) and **Gray/Black** negative (-).
- **White** – Left front speaker positive (+) and **White/Black** negative (-).
- **Violet** – Right rear speaker positive (+) and **Violet/Black** negative (-).
- **Green** – Left rear speaker positive (+) and **Green/Black** negative (-).

Connecting the Wires

Strip about half an inch of insulation from the end of each wire you are connecting. Using crimp connectors or solder, join the corresponding wires from

the Pioneer harness to your adapter harness. If you are working without an adapter, connect the Pioneer wires directly to the vehicle wires based on the colour codes. Wrap each connection securely with electrical tape or cover it with heat shrink tubing. Take your time to ensure each joint is solid because a loose connection can cause intermittent sound or power loss.

For the ground wire (black), attach it to a metal bolt on the vehicle chassis. Some installers connect to the factory ground location if available. Ensure the contact point is free of paint, rust, or dirt to guarantee a good electrical path.

Connecting the Antenna

Plug the antenna cable from your vehicle into the antenna port on the back of the Pioneer DEH 1300MP. If the connector does not fit, you will need an adapter that bridges the factory plug to the standard Motorola-type connector. Most auto parts stores carry these adapters for common vehicle brands.

MOUNTING THE STEREO AND FINALISING THE INSTALLATION

With the wiring complete, it is time to physically install the Pioneer unit into the dashboard. This step requires careful attention to ensure the stereo sits flush

and does not interfere with other dashboard components.

Preparing the Mounting Sleeve

The Pioneer DEH 1300MP uses a metal mounting sleeve that slides into the dash opening. Remove the sleeve from the stereo chassis by pressing the release tabs and sliding it off. Insert the sleeve into the dash kit or directly into the dashboard opening, then bend the metal tabs outward to secure it in place. Use a flat-head screwdriver to push the tabs firmly against the inner edge of the dash. If your vehicle requires a mounting bracket, attach it to the sleeve according to the dash kit instructions before sliding

it into position.

Sliding the Stereo In

Connect the wiring harness and antenna cable to the back of the Pioneer unit. Carefully slide the stereo into the mounted sleeve until it clicks securely into place. Do not force the unit if it meets resistance; check for tangled wires or a misaligned sleeve. Once seated, attach the trim ring that came with the stereo to cover the gap between the unit and the dashboard. This gives the installation a finished, factory-like appearance.

Reinstalling Dashboard Trim

Snap the factory trim panel back into place around the new stereo. Make sure all edges are flush and that no wires are pinched between the trim and the dashboard. Tighten any screws you removed earlier, being careful not to overtighten and crack the plastic.

TESTING YOUR NEW PIONEER DEH 1300MP

Now comes the rewarding part. Reconnect the negative battery terminal and turn the ignition to the accessory position. Press the power button on the stereo. The display should light up, and

you should hear sound through your speakers. Perform the following checks to confirm everything is working correctly.

- Verify that all four speakers produce sound. Adjust the balance and fader settings to test each channel individually.
- Check that the radio tuner picks up FM and AM stations clearly. If reception is weak, ensure the antenna cable is fully connected.
- Insert a CD or MP3 disc and confirm playback. Test the skip, pause, and eject functions.
- Turn the vehicle's headlights on and off to verify that the dimmer wire is working if you connected it. The display brightness should

change accordingly.

- Cycle the ignition off and on to confirm that the stereo powers off and on as expected and that preset radio stations are retained.

If any function does not work as expected, turn off the stereo and disconnect the battery again. Double-check your wiring connections, especially the constant and switched power wires. A multimeter can help you verify voltage at the harness.

TROUBLESHOOTING COMMON INSTALLATION ISSUES

Even with careful preparation, sometimes things do not go perfectly. Here are some common problems and their likely causes.

No power to the stereo. Check the fuse in the back of the Pioneer unit and the vehicle fuse box. Ensure the yellow and red wires are connected to the correct power sources. The ground wire must also be securely attached to bare metal.

Sound only from one side or one speaker. This usually indicates a loose or misconnected speaker wire. Recheck the connections for the affected channel. Also, verify that the speaker itself is functioning.

Poor radio reception. Confirm that the antenna plug is fully inserted. If you used an adapter, try wiggling it to see if reception improves. Sometimes a damaged antenna cable or aftermarket window tint with metallic elements can interfere with signals.

Stereo turns off when the ignition is off but loses memory settings. This means the yellow constant power wire is not receiving battery voltage. Check its connection and the corresponding fuse.

The display is too bright at night. If you connected the orange/white dimmer wire, the display should dim with the headlights. If it remains bright, the dimmer wire may not be connected to the correct vehicle circuit. You can leave it unconnected and manually adjust brightness in the settings, if available.

ENHANCING YOUR AUDIO EXPERIENCE AFTER

INSTALLATION

Once the Pioneer DEH 1300MP is installed, you can fine-tune the audio settings to suit your preferences. The unit offers basic equaliser presets, bass boost, and loudness controls. Experiment with these settings to achieve a balanced sound that complements your vehicle's acoustics. If you plan to add external amplifiers or subwoofers later, the blue/white remote turn-on wire is pre-wired and ready to connect. The front auxiliary input also allows easy connection of smartphones or MP