

---

# iPhone 3g Teardown Guide

---

*iPhone 3g Teardown  
Guide*

*Downloaded from  
[cardprinter.sendafriend.co](http://cardprinter.sendafriend.co)  
by Jax & Simmons*

---

## INTRODUCTION

---

The iPhone 3G, released in 2008, marked a significant evolution in Apple's smartphone lineup. It was the first iPhone to feature 3G connectivity, GPS, and a redesigned plastic back. For many tech enthusiasts, repair technicians, and vintage gadget collectors, understanding how to perform an **iPhone 3G teardown guide** is a valuable skill. Whether you're looking to replace a

worn-out battery, fix a cracked display, or simply satisfy your curiosity about the internal architecture of this iconic device, a proper teardown ensures you can access its components without causing unnecessary damage. This comprehensive guide will walk you through every step of disassembling the iPhone 3G, from gathering the right tools to reassembling the device with confidence.

While modern smartphones are often sealed with adhesive and complex internal layouts, the iPhone 3G is

relatively straightforward to work on — provided you follow the correct procedure. In this article, we'll cover preparation, step-by-step disassembly, a detailed look at each major component, reassembly tips, and solutions to common issues. By the end, you'll have a thorough understanding of the **iPhone 3G teardown guide** and the knowledge to tackle repairs or restorations. Let's begin.

---

## PREPARATION AND TOOLS REQUIRED

---

Before you start your **iPhone 3G teardown guide**, it's crucial to prepare your workspace and gather the necessary tools. Rushing into a disassembly without proper planning can lead to stripped screws, damaged

connectors, or even permanent harm to the device. Below, we outline the essential tools and safety measures.

# Essential Tools for the iPhone 3G Teardown

- **Pentalobe screwdriver (0.8 mm):** Required to remove the two bottom screws near the dock connector.
- **Phillips #00 screwdriver:** For internal Phillips-head screws, including the display bracket and logic board.
- **Flathead spudger or nylon pry**

**tool:** To safely disconnect ribbon cables and pry open the case without scratching components.

- **Suction cup:** Helps lift the front panel assembly from the rear case.
- **Plastic opening tool:** Useful for separating the front panel from the rear case clips.
- **Tweezers (anti-static recommended):** For handling tiny screws and delicate connectors.
- **Magnifying glass or headlamp:** The internal components are small; good lighting and magnification help avoid mistakes.
- **ESD-safe mat or anti-static wrist strap:** To prevent electrostatic discharge that could damage sensitive electronics.

- **Small containers or magnetized tray:** For organizing screws and small parts by location.

## Safety Precautions

1. **Power off the device completely.** A powered-on iPhone 3G can short circuit if tools touch live components.
2. **Remove the SIM card tray** before proceeding; this prevents damage to the SIM slot.
3. **Work in a clean, static-free environment.** Avoid carpets, and use an ESD mat if available.
4. **Handle the battery with care.**

The iPhone 3G uses a lithium-ion battery; puncturing it can cause fire or chemical leaks.

5. **Take photos during disassembly.** This will help you remember cable routes and screw locations for reassembly.

With your tools ready and safety measures in place, you can confidently move on to the step-by-step disassembly process of this **iPhone 3G teardown guide**.

---

## STEP-BY-STEP TEARDOWN PROCESS

---

This detailed walkthrough will guide you through each stage of disassembling the iPhone 3G. Follow the steps sequentially to avoid damaging components.

# Step 1: Remove the SIM Card Tray

Insert a SIM card eject tool (or a straightened paperclip) into the small hole on the right side of the device. Gently push to pop out the SIM tray. Set the tray and SIM card aside in a safe place. This step is often overlooked, but it prevents the tray from catching on the internal components when you separate the front panel.

## Step 2: Remove the Two Bottom Screws

Using the pentalobe screwdriver, remove the two screws flanking the 30-pin dock connector at the bottom edge of the iPhone 3G. These screws are short and have a distinct five-pointed star shape. Place them in a labeled container — they are not interchangeable with other screws in the device.

## Step 3: Separate the Front Panel from the Rear Case

Apply the suction cup to the lower half of the digitizer (the glass above the display). Gently lift to create a small gap. Insert a plastic opening tool into the gap and carefully slide it along the edge to release the plastic clips that hold the front panel to the rear case. Work your way around the entire perimeter. Be patient — the clips are brittle. Once all clips are disengaged, tilt the front panel

up from the bottom, but do not pull it away completely, as the front panel is still connected to the logic board via a set of ribbon cables.

## Step 4: Disconnect the Battery and Other Connectors

With the front panel resting at an angle, you will see the logic board and several ribbon cables. Locate the battery connector on the top-left side of the logic

board (near the rear-facing camera). Use the flathead spudger to gently pry up the battery connector. This cuts power to the device and prevents shorts during further disassembly. Next, disconnect the display and digitizer cables: there are two or three cables clipped to the logic board near the bottom. Lift each connector gently using the spudger. Now you can fully separate the front panel assembly (screen, digitizer, and earpiece) from the rear case.

## Step 5: Remove the Logic Board

With the front panel removed, you have access to the main logic board. Begin by removing the EMI shield (small metal

cover) over the logic board, secured by two Phillips screws. Then disconnect the remaining ribbon cables attached to the logic board: the dock connector, front-facing camera, and audio jack flex cable. Use tweezers to carefully lift the connectors. Finally, remove the two Phillips screws that hold the logic board itself. Gently lift the logic board from the bottom edge, being mindful of any cables that may still be attached. Set the logic board aside in an anti-static bag or on a mat.

## Step 6: Remove

## Other Components (Battery, Speaker, Camera, etc.)

The battery is located at the top of the rear case, adhered with double-sided tape. Using a plastic pry tool, gently lift the battery from the bottom edge. Do not use metal tools as they may puncture the battery. Once removed, you can extract the loudspeaker module (at the bottom left) by prying it from its

## DETAILED COMPONENT

The rear-facing camera (a small cylindrical component) is near the speaker; pop it out using tweezers. The rear-facing camera module is attached to the top-right corner of the rear case — lift it with the spudger. The front-facing camera (if present in later revisions) is part of the front panel assembly. The headphone jack and power button flex cables are also accessible at this stage, but replacement is less common. Take note of each component's original position for reassembly.

Congratulations — you have now fully disassembled an iPhone 3G following this **iPhone 3G teardown guide**. The device is now reduced to its core parts, ready for inspection or repair.

---

## OVERVIEW

---

Understanding the parts you've removed adds context to the teardown and helps with troubleshooting. Below is a brief overview of the major components of the iPhone 3G.

# Battery

The iPhone 3G uses a 3.7V 1150 mAh lithium-ion battery. It is proprietary and soldered to a small connector board. Over time, this battery degrades and may swell, making replacement a common reason for a teardown. Swollen batteries should be disposed of properly.

## Display and Digitizer

The front panel assembly combines the LCD display and touch-sensitive digitizer. These are fused together in the iPhone 3G, meaning you cannot replace one without the other. The assembly connects to the logic board via two main ribbon cables — one for the LCD and one for the digitizer. Cracks in the glass usually require full assembly replacement.

## Logic Board

The logic board houses the CPU (Samsung S5L8900), 128 MB of RAM,

and 8 GB or 16 GB of NAND flash storage. It also includes the WiFi/Bluetooth module, baseband processor, and power management IC. This delicate board is protected by an EMI shield. Handle it with extreme care.

## Rear Camera and Front Camera

The rear camera is a 2-megapixel fixed-focus unit. The front camera was not present in the original iPhone 3G (it appeared in the 3GS). Some later production runs may include a front-facing camera module, but it's rare. Both cameras are easily removable with a spudger.

# Speaker and Vibrator

The loudspeaker is a small module located at the bottom left inside the rear case. It is held in place by friction and a small adhesive. The vibrator motor is a cylindrical eccentric rotating mass (ERM) type, also seated in a bracket.

# Connector Flex Cables

The dock connector, headphone jack, power button, and volume button are all connected via flex cables that plug into the logic board. These cables are fragile

and prone to tearing if not handled gently. They can be replaced individually if damaged.

This component overview gives you a deeper appreciation for the engineering inside the iPhone 3G and aids in diagnosing issues that might require a teardown.

---

## REASSEMBLY TIPS

---

Putting the iPhone 3G back together is essentially the reverse of the disassembly steps, but a few tips will ensure success:

1. **Reconnect the battery last.**

After installing the logic board and all flex cables, connect the battery only after verifying that all other connections are secure.

2. **Align the front panel carefully.**

The plastic clips must snap back into the rear case without forcing them. Start at the top and gently press down around the edges.

3. **Use the correct screws.** The two pentalobe screws from Step 2 must go back into the bottom edge. Using longer screws can puncture the logic board. If you've misplaced them, source exact replacements.

4. **Apply new adhesive if needed.**

The original adhesive strips may lose their grip. Consider using thin double-sided adhesive tape (specifically for mobile phones)

around the front panel edge to ensure a snug fit and prevent dust ingress.

5. **Test before final closure.** Before fully snapping the front panel into place, power on the device to confirm the display, touch, buttons, and camera function correctly. If something doesn't work, reopen and check cable connections.

Reassembly of the iPhone 3G is often more straightforward than with modern devices, but patience and careful alignment remain key. With practice, you can complete the entire process in under 30 minutes.